Manual Load...!!!



Differential Bearing Caps, with Bolts, are manually placed on this conveyor to protect the joint faces. It stores 120 parts in a face to face attitude for delivery to assembly.

Caps are released and staged in pairs on 8.55 inch centers, for robot pickup, at 24 seconds per cycle.





Call: (734) 522-2160 Fax: (734) 522-4671

E-mail: sales@spectrumautomation.com or drop in!

34447 Schoolcraft Road Livonia, MI. 48150

www.SpectrumAutomation.com